

dim sum



SP32547

6/12

APER0 MANDJE 12XH5,5CM+DEKSEL SET/2
COUP APER0 PANIER 12XH5,5CM+COUV SET/2
APER0 BAKER 12XH5,5CM W/LID SET/2



SP32554

6/12

APER0 STEELPAN 11XH6CM SET/2
COUP APER0 POULON 11XH6CM SET/2
APER0 DISH SAUCE POT 11XH6CM SET/2



SP32556

6/12

APER0 MINI TAGINES 6XH5,5CM SET/4
COUP APER0 TAGINES MINI 6XH5,5CM SET/4
APER0 DISH MINI TAGINES 6XH5,5CM SET/4



SP32555

6/12

APER0 TAGINES 11XH10CM SET/2
COUP APER0 TAGINES 11XH10CM SET/2
APER0 DISH TAGINES 11XH10CM SET/2



SP32552

6/12

APEROLEPEL GROOT 15X4,5CM SET/4
CUIILLERE AMUSE-GUEULE 15X4,5CM SET/4
PARTY SPOON LARGE 15X4,5CM SET/4



dim sum

SP32561

6/12

APEROS SAUSKOM 14X5XH6CM SET/2
COUP APERO SAUCIERE 14X5XH6CM SET/2
APEROS DISH SAUCE BOAT 14X5XH6CM SET/2



SP32562

6/12

APEROS SAUSKOM 11X4,5XH5CM SET/2
COUP APERO SAUCIERE 11X4,5XH5CM SET/2
APEROS DISH SAUCE BOAT 11X4,5XH5CM SET/2



SP32549

6/12

APEROS WOKKOMMETJE 16X3,5CM SET/2
COUP APERO WOK 16X3,5CM SET/2
APEROS DISH WOK BOWL 16X3,5CM SET/2



SP32548

6/12

APEROS WOKKOMMETJE 20X4,5CM
COUP APERO WOK 20X4,5CM
APEROS DISH WOK BOWL 20X4,5CM



SP32550

6/12

APEROSCHAALTJE WOKPAN 22XH5CM
COUPELLE APERO WOK 22XH5CM
APEROS DISH WOK 22XH5CM

