



**SP33350**

KOOKPOT 16XH8CM  
CASSEROLE 16XH8CM  
CASSEROLE 16XH8CM

1/6



**SP33351**

KOOKPOT 18XH9CM  
CASSEROLE 18XH9CM  
CASSEROLE 18XH9CM

1/6



**SP33352**

KOOKPOT 20XH10CM  
CASSEROLE 20XH10CM  
CASSEROLE 20XH10CM

1/6



**SP33353**

KOOKPOT 22XH11CM  
CASSEROLE 22XH11CM  
CASSEROLE 22XH11CM

1/6



**SP33354**

KOOKPOT 24XH12CM  
CASSEROLE 24XH12CM  
CASSEROLE 24XH12CM

1/4



**SP33355**

KOOKPOT HOOG 24XH18CM  
CASSEROLE HAUTE 24XH18CM  
STOCK POT 24XH18CM

1/4



**SP33356**

KOOKPOT HOOG 26XH20CM  
CASSEROLE HAUTE 26XH20CM  
STOCK POT 26XH20CM

1/4



**SP33357**

KOOKPOT HOOG 28XH23CM  
CASSEROLE HAUTE 28XH23CM  
STOCK POT 28XH23CM

1/4



**SP33345**

1/6

STEELPAN 16XH8CM ZONDER DEKSEL  
POULON 16XH8CM SANS COUVERCLE  
SAUCEPAN 16XH8CM NO LID



**SP33347**

1/6

STEELPAN 18XH9CM ZONDER DEKSEL  
POELON 18XH9CM SANS COUVERCLE  
SAUCEPAN 18XH9CM NO LID



**SP33358**

1/8

BRAADPAN 20X4CM  
POELE 20X4CM  
FRYING PAN 20X4CM



**SP33360**

1/8

BRAADPAN 24X4,5CM  
POELE 24X4,5CM  
FRYING PAN 24X4,5CM



**SP33362**

1/4

BRAADPAN 28X5CM  
POELE 28X5CM  
FRYING PAN 28X5CM

